

Download Xerox Phaser 3250 Service Manual Parts List

Page 23 Parts List Parts List 8.1 Rear Guide s3250-062 Phaser 3250 Laser Printer Service Manual 9-23... Page 24 Parts List Parts List 8.1 Rear Guide ID No. Name/Description Part Number MEA Unit Guide Rear 032N00491 Guide Rear Roller Idle Exit Bush TX Shaft Exit-F/Up Gear Exit Rubber Exit-F/Up 9-24 Phaser 3250 Laser Printer Service Manual...Xerox Phaser 3250 Service Manual & Parts List. SERVICE PARTS DISASSEMBLY Overview Standard Orientation of the Printer Preparation Notations in the Disassembly Text Fastener Types Maintenance Items and Consumables Print Cartridge (PL1.1.20) Tray Holder Pad (PL11.1.14) Transfer Roller (PL1.1.11) MEA Pick Up Unit (Pick-Up Roller) (PL6.1.26)...Table of Contents viii Phaser 3250 Laser Printer Service Manual 10 Plug/Jack and Wiring Diagrams Plug/Jack Diagrams and Designators ...Phaser® 3250 Black-and-White Laser Printer Phaser® 3250 Service Manual